



Dyna-Cab Installation Guide

This document describes the installation of Dyna-Cabs.

1. Update Fractal-Bot: First, ensure that you have Fractal-Bot version 3.0.18 or newer. You can download it from our web site at <https://www.fractalaudio.com/fractal-bot/> or use the version of Fractal-Bot built into the latest editor for your product.

2. Launch Fractal-Bot and send the DynaCabs file included in the zip file with this document.

- Make sure Fractal-Bot is in **SEND** mode (top buttons).
- For Step 1, **SELECT** your device.
- For Step 2, **BROWSE** to the DynaCab file included with this ReadMe.
Tip: You can drag and drop the file into the field on step 2.
- For Step 3, press **BEGIN** to transmit the file.

3. Wait and Reboot: When the file is finished sending, you will be instructed to reboot your device. Make sure to follow this instruction so the changes can take effect.

By following these steps, you can install the latest DynaCab version, and any warning or error messages should no longer appear.